Repair manual



Table of contents

1. Introduction	1
1.1. Safety precautions	. 1
1.2. Symbols	. 1
2. Main shaft and bearing	. 3
2.1. Front bearing	. 4
2.1.1. Front bearing disassembly	4
2.1.2. Repairing the front bearing	10
2.1.3. Assembly of the front bearing	11
2.1.4. Installing the front bearing	18
2.2. Rear-end bearing	19
2.2.1. Disassembling the rear-end bearing	19
2.2.2. Repairing the rear-end bearings	20
2.2.3. Assembling the rear-end bearing	23
2.2.4. Installing the rear-end bearing	24
2.3. Intermediate shaft	26
3. Impeller	27
3.1. Impeller type	28
3.2. Removing the Impeller	29
3.3. Repairing the impeller	29
3.4. Installing the impeller	30
3.5. Impeller tunnel	34
4. Reversing deflector and operating hydraulics	39
4.1. Reversing deflector	39
4.1.1. Removing the reversing deflector	39
4.1.2. Repairing the reversing deflector	41
4.1.3. Installing the reversing deflector	41
4.2. Operating hydraulics	42
4.2.1. Removing the cylinder	42
4.2.2. Repairing the cylinder	45
4.2.3. Installing the cylinder	46
4.2.4. Cylinder adjustment	50
4.3. Hydraulic pump	53
4.3.1. Removing the hydraulic pump	53
4.3.2. Repairing the hydraulic pump	54
4.3.3. Installing the hydraulic pump	56
4.3.4. Replacing the oil filter	57
5. Steering nozzle and actuating cylinder	59
5.1. Steering nozzle	59
5.1.1. Removing the steering nozzle	59
5.1.2. Repairing the steering nozzle	61
5.1.3. Installing the steering nozzle	61
5.2. Steering cylinder	62
5.2.1. Removing the control cylinder	62
5.2.2. Repairing the control cylinder	63
5.2.3. Installing the control cylinder	64
6. Stator	65
6.1. Removing the stator	65
6.2. Repairing the stator	67
6.3. Installing the stator	69
Appendix 1. Grease recommendations	71
Appendix 2. Oil recommendations	72
Appendix 3. Tightening torques	73

alamarin

1. Introduction

This is the repair manual for Alamarin-Jet's AJ 285 water jet propulsion unit. This manual is intended for the owners, users, and repair persons of boats that are equipped with the Alamarin-Jet water jet propulsion unit. With the help of this manual, they can carry out the most common repair procedures for AJ 285 water jet propulsion units.

© Alamarin-Jet Oy

Tuomisentie 16 FI-62300 Härmä, Finland Telephone: +358 10 7745 260 Fax: +358 10 7745 269 Internet: www.alamarinjet.com

All rights reserved.

The information in this manual may not be copied, published or reproduced in any way whatsoever, or exploited for commercial purposes, without express written permission from Alamarin-Jet Oy.

The information in this manual is subject to change without notice. Alamarin-Jet Oy reserves the right to modify the contents without notice.

1.1. Safety precautions

Read these instructions carefully before carrying out any procedures. Always follow these instructions and the safety precautions shown below.

- Only a person with adequate training is allowed to carry out the procedures described in this manual.
- The person carrying out the procedures must always wear the appropriate protective equipment.
- The work premises must be sufficiently large, safe and well-lit.
- The tools that are to be used must be clean and appropriate for the intended purpose.

1.2. Symbols

Please refer to table 1 for a description of the symbols used in this manual.

Fable	1.	The	symbols	s used	in	the	manual
-------	----	-----	---------	--------	----	-----	--------

Icon	Description
	DANGER
	Negligence in the performance of a procedure can cause a threat to your life.
	WARNING
	Negligence in the performance of the procedures can lead to personal injury, breakdown of equipment, or serious malfunction of the equipment.

alamarin:jet

Icon	Description
	CAUTION
	The procedure involves minor danger or a possibility of minor damage to equipment.
\land	WARRANTY
	The warranty is voided if the procedure is carried out incorrectly.
	NOTE
•	Important notice or fact.
	TIP
	Additional information that facilitates the performance of work or a procedure.
	MAINTENANCE ON LAND
	The boat must be lifted out of the water for maintenance.
	MAINTENANCE IN WATER
	The maintenance procedure can be carried out in water.
	CARRIED OUT BY ONE PERSON
	One person can carry out the procedure.
	CARRIED OUT BY TWO PERSONS
['∏' '∏']	Two persons must carry out the procedure.
	INDICATOR ARROW
•••••	ARROW DESCRIBING MOTION

Please note that this instruction uses the terms "jet" and "jet propulsion unit". They mainly refer to the same thing.

alamarinije

2. Main shaft and bearing

The power from the engine that runs the jet is transmitted to the main shaft using an intermediate shaft. The intermediate shaft is attached to the coupling flange in one end, and either the gear box or the engine flywheel adapter in the other end. The intermediate shaft is often acquired and installed by the manufacturer of the boat and can, therefore, not be discussed in detail in this document. However, some central issues related to it are described at a general level in the section 2.3. *Intermediate shaft*, page 26.

The main shaft of the jet is a direct shaft (figure 1, point A), supported at both ends with bearings. At the front end of the shaft is a coupling flange (figure 1, point B), to which the intermediate shaft is connected. The shaft is also equipped with an impeller (figure 1, point C), connected with a parallel key. The impeller generates pressure as it rotates.



Figure 1. Main shaft and bearing

The front end has a double-cone angular contact ball bearing, receiving axial thrust and radial loads in every direction. The bearing is inside the housing (figure 1, point D), and it is oil-lubricated. The bearing housing seal on the intake duct side is a mechanical rotary seal (figure 1, point E). The shaft seal is on the engine room side.

The rear bearing (figure 1, point F) is attached to the stator. There is a needle bearing, which is lubricated from the engine room with petroleum jelly, within the housing. Alternatively, a water lubricated bearing can be used.

2.1. Front bearing

2.1.1. Front bearing disassembly



Before the bearing can be disassembled, remove

- the stator (section 6.1. *Removing the stator*, page 65)
- the impeller (section 3.2. *Removing the Impeller*, page 29).

Then, remove

- the intermediate shaft from the coupling flange
- the oil pump of the reversing deflector's actuating cylinder (section 4.3.1. *Removing the hydraulic pump*, page 53).

Make sure you also have a container into which you can drain the old oil from the system.

Front bearing disassembly:

1. Detach the lubricating oil reservoir connectors off of the bearing housing (figure 2) and drain the oil from the system.

Drain the oil from the ends of the hoses into a suitable container. Depending on the length of the hoses, the oil reservoir and hoses contain approximately 1 to 2 litres of oil.



Figure 2. Lubricating oil reservoir connectors

2. Remove the coupling flange.

If you need to replace the entire bearing, including the shaft, you can leave the coupling flange in place and the remove the bearing housing screws through the holes on the coupling flange (figure 4, point B).

alamarinije

First detach the cover plate, which is fastened to the coupling flange hub (figure 3).



Figure 3. Coupling flange coverFigplatefas

Figure 4. Coupling flange fastening nut

3. Unscrew the nut (figure 4, point A) and use pliers to remove the spacer under the nut. Pull the coupling flange out of the cone with a sturdy extraction tool.

There is a special tool available that covers and protects the end of the shaft when an extraction tool is used. There is also an extraction tool available as an accessory that is specifically designed for removing the coupling flange. The use of these tools is recommended in order to prevent damage to the end of the shaft. The product code of the extraction tool is 11039 while the product code of the shaft's protective sleeve is 10865.

4. Remove the key from the shaft (figure 5, point A).

alamarin-jet



Figure 5. Removing the bearing housing

- 5. Open the bearing housing screws (6 pcs, figure 5, point B).
- 6. Pull the shaft off the frame.

Use the two M6 holes, from which the screws must first be removed (figure 5, point C). Replace the screws with longer screws or threaded rods, and tighten them until they bottom out. Tighten them evenly until the bearing housing comes loose from the frame.

The bearing housing comes loose together with the shaft, bearings, and the mechanical seal. Pull the bearing housing off the bearings (figure 6).





<u>alamarin jet</u>

7. Turn the lock washer tooth (figure 7, point A) up from the shaft nut groove, and unscrew the shaft nut (figure 7, point B).

The lock washer comes loose when the nut is unscrewed.



Figure 7. Removing the lock washer

8. Pull the bearing (figure 8, point B) off the shaft.

The mechanical seal (figure 8, point D) can also be removed now. However, it may be tight due to the pressure on the shaft that is caused by the rubber bellows.



Figure 8. Removing the bearing from the shaft

Seals

Mechanical seal

<u>alamarin jet</u>

The mechanical seal consists of several parts (figure 9).



Figure 9. Mechanical seal

- A Static slip-ring seal
- B Static slip-ring, pressed to the bearing housing together with the seal
- C Rotating slip-ring
- D Spring for pressing the sealing faces against each other
- E Rubber bellows
- F Sealing support ring

The slip surfaces are of silicon carbide, which is an extremely durable material. In order to achieve a high level of sealing, the surfaces must be perfectly smooth. If the slip surfaces show signs of mechanical damage, the seal must be replaced.

The water on the outside and the oil in the bearing housing both lubricate and cool the slip surfaces.

Support ring F (figure 9) is attached to the shaft with a crimped joint. It can be removed by heating, for example. Parts A and B (figure 9) are removed by pushing them from the bearing side.

O-ring

An o-ring is used as sealing between the bearing housing and the jet's frame (figure 10).

alamarinijet



Figure 10. O-ring

When opening the bearing housing, there may be small amounts of white oil in the rubber bellows of the mechanical seal and the joint surface of the slip-ring. This is a sign of water in the bearing housing. This is completely normal and will not cause any problems. When the shaft rotates, the oil circulates through the oil reservoir and the water gathers at the bottom of the reservoir.

Shaft seals

Two shaft seals that seal the front end of the bearing housing are attached to the bearing housing. The seal lip will rub against the surface of the coupling flange. The shaft seals come off in different directions and are locked in place with safety rings. The front seal can be replaced without detaching the bearing housing from the frame (figure 11).



Figure 11. Shaft seal of the bearing housing

alamarin-jet

A shaft seal is also attached to the coupling flange to keep oil off of the cone joint surface. It can be removed with a screwdriver, for example (figure 12). As this seal does not move against the shaft, it will not wear like the others.



Figure 12. Coupling flange shaft seal

2.1.2. Repairing the front bearing



Under normal circumstances, the operating life of the front bearing is thousands of driving hours. However, if the lubrication weakens due to, for example, the failure of the seal or dirty oil, the operating life of the bearing will decrease rapidly. Using a worn rear bearing also shortens the life span of the front bearing. A worn bearing will make noise and may cause the bearing housing to overheat.

The wearing parts of the front bearing include the bearings, mechanical seal, and front shaft seal. All of the wearing parts and the coupling flange seal should be replaced every time the bearing replaced.

When replacing the bearings, check the following issues:

- straightness of the shaft
- location of the mechanical seal on the shaft (the surface must be free of scratches)
- external condition of the bearing housings
- external condition of the coupling flange (particularly where the shaft seal rubs against the coupling flange).

Measuring the straightness of the shaft

The straightness of the shaft is measured from three points (figure 13).

alamarin:



Figure 13. Measuring the straightness of the shaft

- A Supporting point 1
- B Supporting point 2
- C Measuring point

The maximum permissible deviation measured from the surface of the shaft is 0.15 mm, in which case the dislocation of the centre line is 0.075 mm.



2.1.3. Assembly of the front bearing

	İ

The front bearing must be assembled before it can be reinstalled. Clean all parts of old lubricants and dirt before assembly. Old grease must also be removed from the hole that runs through the shaft.

Assembly of the front bearing:

1. Install the mechanical seal.

Be careful not to damage the slip-ring (figure 14, point B) during installation. If the seal is pressed into its place in a slanted position, and the slip-ring can scratch the surface of the shaft, the slip-ring may be damaged.

- 1.1. Heat the sealing support ring (figure 9, point F) until it slips into its place unobstructed.
- 1.2. Let the parts cool down.
- 1.3. Lubricate the surface of the shaft where the rubber bellows rest (figure 14, point A).



Figure 14. Installing the mechanical seal

The rubber bellows will not move on the shaft surface if it is not lubricated.

CAUTION!
Only special lubricating gel that vaporises between the rubber and shaft may be used for the lubrication.
If the lubricant used for the rubber bellows contains oil, the bellows might rub against the shaft surface and thereby cause insufficient sealing.
If the gel is not available, the bellows may be lubricated with a small amount of water.

The rubber bellows is pressed tightly against the support ring.

- 1.4. Push the rotating part of the mechanical seal (figure 9, points C, D, and E) into place against the support ring.
- 2. Push the static part of the mechanical seal into the bearing housing spacer together with the seal (figure 9, points A and B).

Figure 15 shows the static ring in its correct position.

alamarin-jet



Figure 15. Static ring

- 3. Place the bearings into the bearing housing and press them on to the shaft together (figure 16). Please note that the bearings must be installed in the correct way. See figure 17.
- 4. Position the lock washer on to the shaft and screw the shaft nut in place.

Tighten the nut by first tightening it against the bearings by hand and then use a shaft nut wrench to tighten it enough to make one of the teeth of the lock washer connect with the groove in the nut. Finish by turning the tooth of the lock washer into the shaft nut groove (figure 16, point A).



Figure 16. Pushing the bearings onto the shaft



Figure 17. Bearings (cross-section)

5. Lubricate the inner rims of the bearing housing and press the shaft seals into the bearing housing, right side up (figure 18).

If they are not the right way up, the rear shaft's lubrication grease will be mixed with the lubrication oil on the front bearing (figure 19).



Figure 18. Installing the shaft seals in the bearing housing

<u>alamarin je</u>



Figure 19. Rear shaft lubrication channel

6. Install the safety rings in their grooves to keep the shaft seals in place.

In other words, the shaft seals seal the rear shaft lubrication channel.

7. Press the bearing housing cover on to the bearings, making sure that the lubricating oil connectors are facing the same way. This ensures that the screw holes are aligned (figure 20). Fasten the bearing housing with two M6 screws to a tightness of 9 Nm (figure 20).



Figure 20. Installing the bearing housing

8. Replace the seal in the rear section of the coupling flange. This seal does not necessarily wear since it is static, but when the bearing housing is opened, it is a good idea to replace it. Ensure that the seal is inserted in the correct way (figure 21).

<u>alamarin:jet</u>



Figure 21. Installing the coupling flange shaft seal

- 9. Place the bearing housing fastening screws (6 pcs, figure 22, point A) in the holes and install the coupling flange.
 - 9.1. Place the key in the keyway (figure 22, point B).
 - 9.2. Press the coupling flange against the cone at the end of the shaft. The shaft seal in the coupling flange contacts the key, but if you lift the rear edge of the coupling flange slightly, it will clear the key. The tightening torque for coupling flange nut is 150 Nm. Use a thread locking compound (such as Loctite 242).



Figure 22. Installing the coupling flange

9.3. Install the cover ring on the front surface of the coupling flange. Please note the o-ring in the ring (figure 23).





Figure 23. Cover ring of the coupling flange front surface

It is recommended to check the tightness of the bearing housing during this phase. Use connector A (figure 24) to apply enough grease into the rear bearing's lubrication channel for the grease to discharge through the rear end of the shaft. This ensures that the lubrication channels are full of grease. The rotation of the shaft will become heavier as the seals press against the coupling flange surface. Do not feed grease in too quickly to avoid excessive pressure peaks. If the C seals leak, grease will pour out from the neck of the coupling flange or through connector B. This means that reassembly is required.

Connector B is for the oil lubrication of the front bearing (IN connector). Fill the housing with oil. The OUT connector must have a piece of hose turned upwards to prevent overflow.

Rotate the shaft in different directions several times in order to expose the possible leak points in the mechanical seal.



Figure 24. Lubricating the bearing housing

<u>alamarin:jet</u>

2.1.4. Installing the front bearing



Assemble the front bearing before installing (section 2.1.3. *Assembly of the front bearing*, page 11).

Front bearing installation:

1. Clean the part of the jet's frame where the bearing housing is to be installed.

The installation surface must be free of any old sealing compound or other impurities and be straight.

2. Make sure the seal is tight by spreading sealing compound (such as Sikaflex 291i) on the shoulder (figure 25) at the o-ring.



Figure 25. Shoulder

3. Push the shaft bearing into place through the hole in the jet's frame (figure 26, point A), and tighten the bearing housing fastening screws (six in total, figure 26, point B) through the holes in the coupling flange using a long Allen key (figure 26, point C). Use a thread locking compound (such as Loctite 242).

The tightening torque of the screws is 46 Nm.



<u>alamarin je</u>

Figure 26. Attaching the bearing housing

- 4. Install the impeller (section 3.4. *Installing the impeller*, page 30).
- 5. Install the stator (section 6.3. *Installing the stator*, page 69), the steering nozzle (section 5.1.3. *Installing the steering nozzle*, page 61) and the reversing deflector (section 4.1.3. *Installing the reversing deflector*, page 41)
- 6. Install the hydraulic pump (section 4.3.3. *Installing the hydraulic pump*, page 56).

2.2. Rear-end bearing

2.2.1. Disassembling the rear-end bearing



Rear-end bearing disassembly:

- 1. Remove the stator (section 6.1. *Removing the stator*, page 65).
- 2. The rear bearing housing is attached to the stator with three screws (figure 27). Undo the screws and remove the plastic cover.

<u>alamarin:jet</u>



Figure 27. Rear bearing housing screws

3. Screw one or, if necessary, two of the fastening screws into the threaded holes in the bearing housing flange.



Figure 28. Detaching the rear bearing housing from the stator

- 4. Tighten the screws carefully until the bearing housing comes loose.
- 5. Pull the bearing housing off the stator.

2.2.2. Repairing the rear-end bearings



Repair operations on the rear bearings are limited to replacing worn parts. The wearing parts include the bearing, seals, and shaft sleeves, replaced as necessary. The wearing speed varies according to the load on the jet.



CAUTION!

If the seals are worn, they may allow water to flow into the bearing housing, in turn weakening the lubrication of the bearing and shortening its operating life.

Please note that the greatest permissible radial clearance in the rear bearings is $0.1\ \mbox{mm}.$

Seals



Replacing the seals:

1. Remove the seals with a screwdriver, for example (figure 29).



Figure 29. Removing the rear bearing seals

The second seal is attached to the plastic cover.

2. Replace the old seals with new ones.

Bearing

Replacing the bearing:

1. Push the bearing out of the housing from the front side.

There are holes on the housing race (figure 30) to allow pushing the bearing with a mandrel, for example.



Figure 30. Recess allowing for easy removal of the bearing

Shaft sleeve

There is a sleeve at the rear end of the shaft (figure 31, point A) that keeps the impeller in place. A worn sleeve can be replaced. At the end of the shaft there is a locking plate (figure 31, point B) that presses the sleeve against the impeller. (See 3.4. *Installing the impeller*, page 30).



Figure 31. Shaft sleeve

Removing the shaft sleeve:

Open the screw at the end of the shaft and pull the sleeve off the shaft.

alamarin-je

2.2.3. Assembling the rear-end bearing



Assembly of the rear bearing:

1. Push the bearing into the bearing housing from the back (figure 32).

Use a bearing retaining compound to ensure that the bearing stays in place (such as Loctite 648 or similar).



Figure 32. Assembly of the rear bearing

2. Push the seal into place from the front of the bearing housing.

The second seal is attached to the plastic cover. Ensure that the seals are inserted in the correct way (figure 33).

<u>alamarin:jet</u>



Figure 33. Installation direction of the seals

2.2.4. Installing the rear-end bearing



Before installation, ensure that the bearing housing hole in the stator is clean and intact.

Installing the rear-end bearing:

1. Spread adhesive sealing compound around the bearing housing on the area indicated in figure 34 .



Figure 34. Spreading area of the adhesive compound

2. Push the bearing housing into the hole on the stator (figure 35, point A).





Figure 35. Installing the bearing housing cover

3. Press the bearing housing into the stator hole in the correct position so that the three fastening screw holes (figure 35, point C) are aligned. This is when the housing is in the correct position. Install the cover (figure 35, point B) in place and tighten the fastening screws. Use a thread locking compound (such as Loctite 242).

The tightening torque of the screws is 10 Nm.

- 4. Remove excess adhesive compound from the hole (figure 35, point D).
- 5. Install the sleeve at the end of the shaft on to the shaft along with the oring.

The correct installation sequence is illustrated in figure 36.

Use thread locking compound (such as Loctite 243) on the fastening screw in order to prevent any unintentional loosening of the screw.



Figure 36. Installation sequence of the sleeve

6. Install the stator (section 6.3. *Installing the stator*, page 69).

2.3. Intermediate shaft

The intermediate shaft is the transmission shaft between the motor and jet. Usually, the intermediate shaft has been acquired and installed by the boat manufacturer.

The most common types of intermediate shaft are the constant speed shaft and the cardan shaft. In addition, various flexible shaft couplings are used.

The intermediate shaft is attached to the jet's coupling flange and the flywheel or gearbox. An adapter flange can be used between the jet and the shaft.

The manufacturer's instructions must always be followed in the maintenance, repair, and installation of the intermediate shaft.

alamarinije

3. Impeller

The impeller (figure 37, point A) is attached to the jet's main shaft. As the impeller rotates, it generates pressure that is then transformed into the flow rate.



Figure 37. Impeller

The impeller is attached to the shaft with a mounting flange (figure 37, point B), which is attached to the impeller with bolts (6 pcs, figure 37, point C). The torque is transmitted to the shaft using a key. The impeller is held in place by a sleeve (figure 37, point D) attached to the rear end of the shat with a screw.

The impeller is located in the cone duct, which allows the gap between the blade and the duct wall to be quite small.

There are rings of various thicknesses (figure 38, point A) on the front side of the impeller. These define the location of the impeller in the duct and transmit the thrust from the impeller to the shaft. A plastic insulating ring must always be present in front of the impeller (figure 38, point B).

alamarin-jet



Figure 38. Impeller rings

3.1. Impeller type

The type of the impeller is defined according to the number, pitch, and surface area of the blades. The number and total pitch of the blades are unambiguous, but the surface area may vary according to the diameter and length of the blades.

The impeller type that is used varies according to the situation because the AJ 285 can be attached to various types of motors. Therefore, each impeller must be type-marked. The type marking has been punched into the rear of the impeller hub (figure 39). The type of the impeller must be declared, for example, when ordering a new impeller. The format of the type marking is "285-X/N+T.



Figure 39. Impeller type marking

3.2. Removing the Impeller



Before removing the impeller, remove the stator (section 6.1. *Removing the stator*, page 65).

Removing the impeller:

- 1. Open the screw keeping the sleeve (figure 37, point D) at the rear end of the shaft in place and pull the sleeve off the shaft.
- 2. Remove the shim rings that may be present between the impeller and the shaft sleeve.

Do not lose the shim rings and be sure to keep them separate from the ones in front of the impeller! This will make adjusting the impeller easier.

3. Pull back the impeller off of the shaft and remove the key from the keyway.

3.3. Repairing the impeller



Minor damages on the impeller can be repaired. Examples of this are dents to the front edge that can be ground out, and slightly bent blades that can be hammered back into their original position.



If the diameter of the impeller becomes too small, the impeller must be replaced.

The impeller is manufactured from acid-proof steel 1.4460 (AISI329).

Sanding the front edge

If necessary, a worn front edge can be sanded down. Please note that the front edge may not be too sharp or too round. A suitable rounding is approximately r = 1 mm (figure 40).

<u>alamarin:jet</u>



Figure 40. Front edge

Repairing bent blades

Bends in the blades can be carefully tapped back into their original shape with a hammer.

3.4. Installing the impeller



New and repaired impellers are fitted in the same way.

Installing the impeller:

- 1. If the impeller mounting flange was detached from the impeller, re-attach it.
- 2. Lubricate the flange seals with waterproof petroleum jelly (such as Shell Gadus S2 V220AC or similar) and push the sleeve into place.

Note the position of the keyway, which is indicated on the impeller hub (figure 41). Apply thread locking compound (such as Loctite 242) to the screws and tighten them to 80 Nm.

alamarin-jet



Figure 41. Position of the keyway

The thrust caused by the impeller is transmitted through the adjuster sleeve to the shaft (figure 42, point A). The sleeve consists of rings of different thickness. The length of the sleeve can be adjusted in 0.5 mm (approx. 0.02") increments by changing the number of the rings. This way the impeller gap on the outer race becomes fit.



Figure 42. Adjuster sleeve

Find the right sleeve thickness by testing as follows:

- 3. Lubricate the shaft and the inner surface of the impeller mounting flange with waterproof petroleum jelly (such as Shell Gadus S2 V220AC or similar).
- 4. Place the impeller into the duct and push it against the shim rings.
- 5. Measure the gap on the impeller outer race.

If the front surface of the impeller hub does not reach the shim rings, add more shim rings.

The optimal gap is 0.8–1.2 mm (approx. 0.031–0.047") at the upper part of the duct. When you measure the gap, note that the shaft is not centred when the stator is removed, but the shaft's rear end hangs low and the whole gap is visible in the upper part of the duct.



CAUTION!

If the gap is too big, it will cause loss of power and reduce performance.

6. Once you have found the right adjuster sleeve length, place they key lubricated with waterproof petroleum jelly (such as Shell Gadus S2 V220AC or similar) in the shaft keyway (figure 43) and push the impeller onto the shaft against the adjuster sleeve.


Figure 43. Keyway

If you adjusted the impeller during periodical maintenance and had to remove shim rings due to the impeller having worn down, do not throw away the shim rings. They are placed between the impeller and the shaft sleeve (figure 44). When installing a new impeller with a larger diameter, shim rings are moved from the back of the impeller to the front (figure 45).



Figure 44. The impeller moves forward (wearing/gap needs to be reduced)

Figure 45. The impeller moves backward (new impeller/gap needs to increased)

7. Lubricate the the inner surface of the sleeve to be placed at the end of the shaft with waterproof petroleum jelly (such as Shell Gadus S2 V220AC or similar).

- 8. Place the o-ring on to the shaft against the shoulder (figure 46, point A) and the shim rings against the rear surface of the impeller.
- 9. Push the sleeve on to the shaft.

Checking the position of the sleeve:

You can check whether there is an adequate number of shim rings behind the impeller by measuring distance d from the end of the shaft to the rear end of the sleeve (figure 46). The correct distance is 3.5 mm.



Figure 46. Checking the position of the sleeve

1. Once the sleeve is correctly positioned, place the locking plate to the end of the shaft and tighten the rear screw to a torque of 46 Nm.

Apply thread locking compound (such as Loctite 242) to the screw.

2. Make sure that the impeller cannot move forwards of backwards from its place.

3.5. Impeller tunnel



The impeller spins inside a tunnel with an aluminium exterior surface (figure 47, point A) and an inner cone made of acid-proof steel (figure 47, point B). The inner cone is not an actual wearing part as the cone shape enables the impeller to be adjusted more deeply, in order to maintain a small clearance. However, if the inner cone is damaged, the entire impeller tunnel can be replaced.

alamarin-jet



Figure 47. Impeller tunnel

Removing the impeller tunnel

Before removing the impeller tunnel, detach the stator (section 6.1. *Removing the stator*, page 65) and the the impeller (section 3.2. *Removing the Impeller*, page 29).

- 1. Open the connection to the raw water line at the pipe end on the engine room side (figure 48, point A).
- 2. Screw the raw water pipe to disconnect it from the rear end (figure 48, point B). However, you can leave it attached to the frame.



Figure 48. Raw water line

- 3. Open the tunnel locking nuts (8 pcs, figure 47, point C).
- 4. Pull the tunnel off the frame.

You can assist the detachment by inserting a blunt wedge in the holes included for this purpose (figure 49).



Figure 49. Removing the impeller tunnel from the frame

Installing the impeller tunnel

- 1. Ensure that the o-ring between the impeller tunnel and frame is in place. Apply waterproof petroleum jelly onto the connecting surface (such as Shell Gadus S2 V220AC or similar) (figure 50, point A).
- 2. Ensure that the set screws (8 pcs) are in their correct places in the frame. If they have come loose, they must be reinstalled with thread locking compound (such as Loctite 242) (figure 50, point B).

- 3. Ensure that the dowel pins of the impeller tunnel are in place (figure 50, point C).
- 4. Press the impeller tunnel into place.
- 5. Tighten the nuts and the washers (8 pcs) into place to a torque of 46 Nm.



Figure 50. Installing the impeller tunnel

4. Reversing deflector and operating hydraulics

The purpose of the reversing deflector is to create sufficient reverse thrust for reversing the boat. When the deflector (figure 51, point A) is lowered in front of the jet flow, it will turn the jet flow entirely or partially towards the bow, creating thrust. The operating principle allows for stopping even from high speeds because the deflector can be lowered even at full speed.

alamarin-jet

The reversing deflector is used through a hydraulic cylinder, controlled mechanically (figure 51, point B). A cable runs from the handle in the cabin to the operating lever of the cylinder (figure 51, point C). The hydraulic cylinder receives its power from a pump integrated in the jet (figure 51, point D), rotated from the coupling flange with a V belt.



Figure 51. Reversing deflector and operating hydraulics

4.1. Reversing deflector

4.1.1. Removing the reversing deflector

	İ
--	---

Removing the reversing deflector:

1. Open the joint screw of the intermediate bar between the hydraulic cylinder and the reversing deflector (figure 52, point A).



Figure 52. Removing the reversing deflector

2. Open the joint pin screws (2 pcs, figure 53).



WARNING!

Be careful not to drop the deflector.

The deflector weighs approximately 16 kg.



Figure 53. Joint pin screws

3. If you need to replace the plastic bearings on the joint pins, they can be removed with a suitable mandrel.

The plastic bearings are pushed to their place and can be removed by pushing (figure 54).





Figure 54. Removing the plastic bearings

4.1.2. Repairing the reversing deflector



The wearing parts of the reversing deflector are the plastic bearings and anodes. When the gap in the plastic bearings of the joint pins expands too much, the bearings must be replaced. The greatest permissible radial clearance is +1 mm. The articulation bearing of the hydraulic cylinder intermediate bar must also be replaced as necessary. The greatest permissible radial clearance is +1 mm.

The reversing deflector is cast aluminium (AlSi7Mg), and minor breakages can be repaired by welding. The filler metal for the welding is AlMg5. If the arms show breakages, the deflector must be replaced, not repaired.



4.1.3. Installing the reversing deflector



Installing the reversing deflector:

1. Push the plastic bearings of the joint pins and the hydraulic cylinder intermediate bar into their places.

Take note particularly of the direction of the joint pin bearing flange (figure 55).

<u>alamarin:jet</u>



Figure 55. Direction of the plastic bearing flange

- 2. Lift the reversing deflector in place and push the joint pins in the holes.
- 3. Tighten the fastening screws (2 on each side) (figure 56).



Figure 56. Attaching the joint pins

4. Attach the joint screw of the hydraulic cylinder intermediate bar (figure 52, point A).

Please note that there must be a sleeve in the reversing deflector's hole.

4.2. Operating hydraulics

4.2.1. Removing the cylinder





Before you remove the cylinder, make sure you have a container for draining the oil from the hoses. Please note that it may not be necessary to completely drain the system: you can also put plugs at the ends of the hoses.

Removing the cylinder:

- 1. Remove the cable from the cylinder.
 - 1.1. Remove the cable angle joint (figure 57, point A) from the control lever.



Figure 57. Removing the cable

- 1.2. Remove the saddle mounting from the cable bracket (figure 57, point B).
- 2. Remove the cylinder pressure hose (figure 58, point A) and return hose (figure 58, point B) from the valve and drain the oil into a container.

Alternatively, you can plug the ends of the hoses.

<u>alamarin;jet</u>



Figure 58. Removing the hoses

3. Open the joint screw of the intermediate bar between the hydraulic cylinder and the reversing deflector (figure 59, point A).



Figure 59. Removing the cylinder

4. Open the fastening nut of the hydraulic cylinder (figure 59, point B).

If you cannot open the nut with conventional tools, you can use special tool 10718.

5. Unscrew the cylinder from the jet's frame towards the engine room.





Figure 60. Pushing the cylinder

4.2.2. Repairing the cylinder



Worn or damaged parts of the cylinder can be replaced.

The product code for the sealing kit is P9904.



The cylinder rear end seal (figure 61, point A) is a wearing part and must be replaced regularly. The replacement can be performed with the cylinder in place.

The seal sleeve must be replaced as an assembly as disconnecting the seal damages the seal groove. The sleeve is also subjected to wear when the cylinder is operated.

The code for the seal sleeve kit is P9909.

Replacing the cylinder rear end seal:

1. Open the cylinder's intermediate bar joint screw if the cylinder is closed (figure 61, point B).

<u>alamarin-jet</u>



Figure 61. Cylinder rear end seal

- 2. Unscrew the seal sleeve using the holes in the sleeve.
- 3. Install the new sleeve, making sure to apply some sealing compound (such as Sikaflex 291i) to the thread.
- 4. Attach the cylinder's intermediate bar joint screw if the cylinder is installed in place (figure 61, point B).

4.2.3. Installing the cylinder



The cylinder is installed in the reverse order to which it was removed.

- 1. Clean the cylinder attachment hole and thread in the frame (figure 62, point A).
- 2. Screw the locking nut on to the thread at the end of the cylinder in the correct position (figure 62, point B).
- 3. Screw the cylinder onto the threads in the frame. It is a good idea to apply some lubricant to the thread to prevent it from seizing up (figure 62, point C).





Figure 62. Installing the cylinder



alamarin:jet



Figure 63. Cylinder dimensions

4. When the correct measurement X \sim 31 mm is met (figure 63), apply some sealing compound (such as Sikaflex 291i) to the thread, and tighten the nut. You can turn the cylinder slightly if you want the cable clamp to point directly in the cable's direction of entry (figure 64).





Figure 64. Adjusting the cylinder's position

If the nut cannot be tightened with a normal wrench, special tool 10718 is available.

 $5. \ \ \, In stall the intermediate bar between the cylinder and the deflector.$

Check the correct alignment of the bar (figure 65).



Figure 65. Installing the cylinder's intermediate bar



4.2.4. Cylinder adjustment



When you start the engine for the first time, make sure that you have oil available to add to the reversing deflector control hydraulic system.

Fill the reservoir with oil before you start the engine. After you start the engine and put it into forward gear, the oil is transferred from the reservoir into the system and the pump automatically removes air from the system. If the oil level decreases in the reservoir, add some oil through the oil reservoir cap. There is a dipstick in the reservoir that you can use to check the oil level (figure 66). Occasionally move the hydraulic cylinder's operating lever back and forth (figure 67) so that the cylinder fills with oil.



Figure 66. Checking the oil level

- A Maximum level
- B Minimum level
- C Cap





Figure 67. Operating lever

Adjusting the cylinder:

1. Detach the control cable from the end of the cylinder operating lever (figure 68, point A).



Figure 68. Removing the control cable

- 2. Loosen the operating lever screw (figure 68, point B) but do not pull the lever off the shaft yet.
- 3. Place the lever against the limiter on the shaft (figure 69, point A).

<u>alamarin:jet</u>



Figure 69. Operating lever and limiter

- 4. Turn on the engine and put it into gear.
- 5. Using a wrench, turn the operating shaft (figure 69, point B) 13 mm (0.4") clockwise so that the reversing deflector is down, blocking the jet flow.

If you turn the shaft too much, it will no longer move smoothly, indicating that the cylinder has reached the end of its movement range. If this happens, turn the shaft back slightly.

6. Attach the operating lever to the shaft with a screw, and tighten the screw.

The tightening torque is 10 Nm. Do not tighten the screw too much!

- 7. Attach the control cable to the screw at the end of the operating lever (figure 68, point A).
- 8. Use the control system in the cabin to check that the deflector can move to the up and down positions.

In the up position, the deflector does not block the jet flow (figure 70). In the down position, the top of the reversing deflector nearly touches the steering nozzle (figure 71).



Figure 70. Deflector in the up position

<u>alamarin je</u>



Figure 71. Deflector in the down position

4.3. Hydraulic pump

4.3.1. Removing the hydraulic pump



Before you remove the hydraulic pump, ensure that you have a container for draining the oil from the hoses. Please note that it may not be necessary to completely drain the system: you can also put plugs at the ends of the hoses.

Removing the hydraulic pump:

1. Remove the hydraulic pump pressure hose (figure 72, point A) and suction hose (figure 72, point B) and drain the oil into a container.

Alternatively, you can plug the ends of the hoses.



Figure 72. Hoses of the hydraulic pump

2. Remove the hydraulic pump bracket by opening its fastening screws.

The bracket is attached to the front surface of the bearing housing with four screws, two on each side of the pump (figure 73).

<u>alamarin:jet</u>



Figure 73. Hydraulic pump bracket fastening screws

3. Remove the hydraulic pump from the bracket by opening its fastening screws (3 pcs, figure 74).





4.3.2. Repairing the hydraulic pump



A worn belt pulley in the hydraulic pump can be replaced. It can also be replaced with the pump attached to the bracket.

The pump's pressure relief valve may get clogged up with debris, which may cause the pump to malfunction. The pressure relief valve can be checked and cleaned even when the pump is attached to its bracket.



Replacing the belt pulley:

- 1. Loosen the fastening screws of the hydraulic pump rack (figure 73).
- 2. Open the three screws that attach the belt pulley to the rack (3 pcs, figure 75).



Figure 75. Belt pulley fastening screws

- 3. Remove the old belt pulley.
- 4. Fit in the new belt pulley.
- 5. Tighten the screws.

The tightening torque is 23 Nm. Use thread locking compound.

Pressure relief valve disassembly

Reserve a container for this procedure into which you can drain the oil from the partially dissembled system.

1. Open the cylinder-side end of the pressure hose and disconnect the pressure hose from the pump.

If the pump-side end of the hose is equipped with a banjo connection, the cylinder-side connector does not need to be detached.

2. Open the adapter nut (figure 76)



Figure 76. Hydraulic pump pressure relief valve

3. Lift out the pressure relief valve (figure 77) and clean it of any debris and impurities.



Figure 77. The hydraulic pump and the pressure relief valve

- 4. Set the cleaned pressure relief valve back in the pump.
- 5. Tighten the adapter nut.

The tightening torque is 40 Nm.

4.3.3. Installing the hydraulic pump



Installing the hydraulic pump:

1. Mount the hydraulic pump in the bracket using fastening screws (figure 74).

The tightening torque is 23 Nm. Use thread locking compound.

2. Set the bracket against the front surface of the bearing housing and tighten the fastening screws (figure 73) loosely.

Use thread locking compound.

- 3. Set the belt in its place and lift the bracket until the belt tightens.
- 4. Tighten the bracket fastening screws at the same time.

The tightening torque is 46 Nm.

- 5. Install the pressure hose (figure 72, point A) and return hose (figure 72, point B).
- 6. Fill the oil reservoir with oil and use the system (motor running, in forward gear), moving the reversing deflector up and down several times.

This removes air from the system.

4.3.4. Replacing the oil filter



The oil filter in the oil reservoir must be replaced after every 500 operating hours.

Replacing the oil filter:

1. Open the six cover screws (figure 78)



Figure 78. Oil reservoir cover screws

The filter is located under the cover and has a spring on top of it that keeps the filter in place (figure 79).



Figure 79. Oil filter spring

2. Remove and replace the spring and the filter.

It is not necessary to replace the spring unless it is damaged.

3. Put the cover back into place.

Make sure that the cover seal is correctly positioned in the groove (figure 80, point A). The cover must also be positioned correctly so that the spring is in line with its support (figure 80, point B).



Figure 80. Oil reservoir cover

4. Reattach the six cover screws (figure 78).

alamarin-jet

5. Steering nozzle and actuating cylinder

The steering nozzle (figure 81, point A) is used to turn the direction of the water from the jet, causing the boat to turn. The steering nozzle is turned with a hydraulic cylinder (figure 81, point B).



Figure 81. Steering nozzle and actuating cylinder

5.1. Steering nozzle

The steering nozzle can also be removed when the boat is in water, but it is easier if the boat is out of the water.

5.1.1. Removing the steering nozzle



1. Open the connection of the reversing deflector intermediate bar (figure 82) and lower the deflector.

Please note that the steering nozzle must be straight when the deflector is lowered.



Figure 82. Reversing deflector intermediate bar connection

- 2. Detach the steering cylinder connection from the steering nozzle (figure 83, point A).
- 3. Open the steering nozzle joint screws (figure 83, point B).



Figure 83. Removing the steering nozzle



5.1.2. Repairing the steering nozzle



A worn or damaged intermediate bar 11134, joint pivot 11137, joint pivots 11331 (2 pcs), lock washer 11332 and anode can be replaced from the steering nozzle.

The steering nozzle is cast aluminium (AlSi7Mg), and minor breakages can be repaired by welding. The filler metal for the welding is AlMg5. If the swinging arm or shaft holes show breakages, the steering nozzle must be replaced, not repaired.



NOTE!

Bare aluminium areas must be painted when welding the steering nozzle. Use paints suitable for aluminium. Check the correct paint type from the paint supplier.

5.1.3. Installing the steering nozzle



- 1. Make sure that the steering nozzle joint pivot washer (figure 84, point A) and locking screw (figure 84, point B) are in place.
- 2. Place the steering nozzle between the stator joint holes and set the upper joint pivot in place (figure 84, point C).

Make sure that the groove on the edge of the sleeve is pointing backwards



Figure 84. Nozzle joint pivots

- 3. Place a lock washer on top of the joint pivot and tighten the screw fingertight.
- 4. Attach the lower joint pivot and tighten it finger-tight.

alamarin:jet

- 5. Tighten the screws to a torque of 65 Nm.
- 6. Attach the cylinder intermediate bar with the steering nozzle's joint pivot and screw.

Use a thread locking compound (such as Loctite 242) and tighten the screw to a torque of 65 $\rm Nm.$

7. Attach the connection of the reversing deflector intermediate bar (figure 82).

5.2. Steering cylinder

5.2.1. Removing the control cylinder



1. Remove the hydraulic hoses from the cylinder (figure 85, point A).



Figure 85. Cylinder hydraulic hoses

2. Remove the connection between the steering cylinder intermediate bar and piston rod (figure 86).





Figure 86. Connection between the steering cylinder intermediate bar and piston rod

3. Open the fastening nut of the cylinder (figure 85, point B).

If the opening is not possible with normal tools, you can use special tool 10718.

4. Unscrew the cylinder from the jet's frame towards the engine room.

5.2.2. Repairing the control cylinder

Worn or damaged parts of the cylinder can be replaced.

The product code for the sealing kit is P9908.

NOTE!

Only a person with appropriate training is allowed to open the cylinder or carry out the maintenance and repair operations of the cylinder.

The cylinder rear end seal (figure 61, point A) is a wearing part and must be replaced regularly. The replacement can be performed with the cylinder in place.

The seal sleeve must be replaced as an assembly as disconnecting the seal damages the seal groove. The sleeve is also subjected to wear when the cylinder is operated.

The code for the seal sleeve kit is P9909.

alamarin:jet

Replacement is described in section 4.2.2. *Repairing the cylinder*, page 45.

5.2.3. Installing the control cylinder



The control cylinder is installed in the same way as the reversing deflector cylinder. This is described in section 4.2.3. *Installing the cylinder*, page 46.

<u>alamarin je</u>

6. Stator

6.1. Removing the stator



The stator can be removed as a complete unit with the reversing deflector and steering nozzle or one part at a time.

Detachment one part at a time:

- 1. Remove the reversing deflector and the steering nozzle (sections 4.1.1. *Removing the reversing deflector,* page 39 and 5.1.1. *Removing the steering nozzle,* page 59).
- 2. Open the stator fastening screws (8 pcs, figure 87).



Figure 87. Stator fastening screws

3. Pull the stator off.

If the stator cannot be detached easily, you can use a screwdriver by inserting it between the stator and impeller tunnel (figure 88). There is a groove in the seal between the parts for inserting the screwdriver.



Figure 88. Removing the stator

Removing the stator as a complete unit:

- 1. Remove the joint between the reversing deflector and the hydraulic cylinder (figure 82) as well as the joint between the steering nozzle and the steering cylinder (figure 83, point A).
- 2. Open the six fastening screws of the stator (8 pcs, figure 87).
- 3. Remove the stator carefully using a screwdriver (figure 88).
- 4. Pull the stator, the steering nozzle and the reversing deflector out as a single assembly (figure 89).



Figure 89. Removing the stator as a complete unit

6.2. Repairing the stator



Replaceable parts in the stator include:

- seals (figure 90, points A and B), seal B is between the choker and the stator
- choker (figure 90, point C).
- anodes (figure 90, points D and E)
- steering nozzle plastic bearings (figure 90, point F)



Figure 90. Stator's replaceable parts

The stator is cast aluminium (AlSi7Mg), and minor breakages can be repaired by welding. The filler metal for the welding is AlMg5.

Typically the tips of the blades suffer most damages in the stator (figure 91). These kinds of damage can be prevented by repair painting any minor damage.

If the steering nozzle pivots show breakages, the part must be replaced, not repaired.



Figure 91. Stator blades



Seals

Leaking seals must be replaced.

Changing the choker seal:

- 1. Remove the choker (figure 90, point C) fastening screws (6 pcs).
- 2. Pull the choker off.
- 3. Remove the old seal (figure 92).



Figure 92. Choker seal

4. Place the new seal in the groove with waterproof petroleum jelly (such as Shell Gadus S2 V220AC).
alamarin jet

5. Fasten the choker back into place.

The tightening torque of the fastening screws is 10 Nm. Use a thread locking compound (such as Loctite 242) for the fastening.

6.3. Installing the stator



1. Ensure that the stator seal is undamaged and the dowel pins are in place either in the stator or the impeller tunnel (figure 93).



Figure 93. Installing the stator

- 2. Clean the end of the impeller shaft and push the stator into place so that the shaft end enters the rear bearing housing and the dowel pins enter the holes that are intended for them.
- 3. Tighten the screws evenly to a torque of 46 Nm.

alamarin-je

Appendix 1. Grease recommendations

The grease used for lubricating the propulsion unit bearing must meet the following requirements:

- lithium soap and a thickener with EP additives
- mineral oil as a base oil
- NLGI class 2
- operating temperature range -25 to 130°C (-13-266 °F)
- continuous operating temperature min. 75 °C (167 °F)

Recommended grease brands:

- Würth Multi-Purpose Grease III
- FAG Multi2
- FAG Load 220
- Mobil XHP 222
- Neste Allrex EP2
- Shell Retinax Grease EP2

A grease that has equivalent properties to those mentioned above can also be used for lubrication.

Appendix 2. Oil recommendations

The operating hydraulic system of the reversing deflector and the lubrication of the front bearing are designed to use oil that is specifically intended for automatic transmission systems. The oil must meet the following requirements:

Kinematic viscosity 40°C Kinematic viscosity 100°C Viscosity index Density 15°C Pour point Flashpoint 33-36 mm²/s 7.1-7.7 mm²/s min. 170 0.835-0.890 g/cm³ max. -42 °C min. 180 °C

Recommended oil brands:

- Mobil ATF 320
- FormulaShell ATF DEXRON III
- Neste ATF-X
- BP Autran DX III

Appendix 3. Tightening torques

Use the tightening torques from the table 2 when tightening the propulsion unit screws. The strength grade of an acid-proof A4-80 screw is equivalent to a class 8.8 screw.

	Strength grade		
	8.8	10.9	12.9
Thread	Tightening torque (Nm) (*)		
M5	5.5 (4)	8.1 (6)	9.5 (7)
M6	9.6 (7)	14 (10)	16 (12)
M8	23 (17)	34 (25)	40 (30)
M10	46 (34)	67 (49)	79 (58)
M12	79 (58)	115 (85)	135 (100)
M16	145 (107)	215 (159)	250 (184)

Table 2. Tightening torques of the screws

(*) The tightening torque in pound-feet (approximate value) is marked in the table in parentheses after the corresponding value in Nm.

A suitable thread locking compound that is good for all purposes is one of medium strength, for example. Loctite 242 or similar.